
# **BookletChart**

## Keku Strait - Monte Carlo to Entrance Island

(NOAA Chart 17372)




A reduced scale NOAA nautical chart for small boaters. When possible, use the full size NOAA chart for navigation.

- ☑ Complete, reduced scale nautical chart
- Print at home for free
- ☑ Convenient size
- ☑ Up to date with all Notices to Mariners
- ☑ United States Coast Pilot excerpts

☑ Compiled by NOAA, the nation's chartmaker. ND ATM



Approximate Page Index	737
KKU STM OVIC CAMP OF THE PROPERTY OF THE PROPE	7
	1
	2 Hory
	9
17372 SOLADAGS IN FEET TOTAL T	17372



#### **What are Nautical Charts?**

Nautical charts are a fundamental tool of marine navigation. They show water depths, obstructions, buoys, other aids to navigation, and much more. The information is shown in a way that promotes safe and efficient navigation. Chart carriage is mandatory on the commercial ships that carry America's commerce. They are also used on every Navy and Coast Guard ship, fishing and passenger vessels, and are widely carried by recreational boaters.

#### What is a BookletChart<sup>™</sup>?

This BookletChart is made to help recreational boaters locate themselves on the water. It has been reduced in scale for convenience, but otherwise contains all the information of the full-scale nautical chart. The bar scales have also been reduced, and are accurate when used to measure distances in this BookletChart. See the Note at the bottom of page 5 for the reduction in scale applied to this chart.

Whenever possible, use the official, full scale NOAA nautical chart for navigation. Nautical chart sales agents are listed on the Internet at <a href="http://www.NauticalCharts.NOAA.gov">http://www.NauticalCharts.NOAA.gov</a>.

This BookletChart does NOT fulfill chart carriage requirements for regulated commercial vessels under Titles 33 and 44 of the Code of Federal Regulations.

#### **Notice to Mariners Correction Status**

This BookletChart has been updated for chart corrections published in the U.S. Coast Guard Local Notice to Mariners, the National Geospatial Intelligence Agency Weekly Notice to Mariners, and, where applicable, the Canadian Coast Guard Notice to Mariners. Additional chart corrections have been made by NOAA in advance of their publication in a Notice to Mariners. The last Notices to Mariners applied to this chart are listed in the Note at the bottom of page 7. Coast Pilot excerpts are not being corrected.



# [Coast Pilot 8, Chapter 7 excerpts]

(159) **Skiff Island** (56°31.1'N., 133°41.0'W.), on the E side of the bay at the S end of Keku Strait, is low and wooded and is surrounded by rocks and reefs. A small-boat passage is E of the island.

(161) **Monte Carlo Island**, near the center of the bay, is a relatively large, low, wooded islet, 2.5 miles SSW of the entrance to Rocky Pass. It is surrounded by foul ground, particularly to the S, E, and N. Clear of the

foul ground to the N, is a passage leading to the W that affords indifferent anchorage in 6 to 7 fathoms, sticky bottom. The small cove on the N side of the island affords anchorage for small craft, but the entrance is difficult because of the numerous rocks and reefs.

(162) Rocky Pass has its S entrance about 8 miles N of Point Barrie.

(165) The depths through Rocky Pass are generally shallow, and small craft can anchor practically anywhere with the aid of the chart. Larger craft can enter the S end of the pass for a distance of 2 miles until opposite **Tunehean Creek** and select anchorage according to draft, either to N or S of the midchannel reef off the mouth of the creek. At the N end of Rocky Pass, larger craft can anchor in Big John Bay, Stedman Cove, or in the channel as far S as 1 mile below High Island.

(166) **Devils Elbow**, about 14 miles N of Point Barrie, is the most dangerous part of the pass. The channel here makes a full right-angle turn. It had a controlling depth of 5 feet in April 2001.

(170) **The Summit** is the narrow passage, W and NW of Summit Island, through which a channel has been dredged. The channel had a controlling depth of 3.5 feet (4.1 feet at midchannel) in April 2001. Passage through The Summit should be attempted only with local knowledge.

(172) **High Island**, about 10.5 miles N of Keku Strait S entrance and 1.8 miles S of Beacon Island, is the largest island in Keku Strait. The W arm of the island has a conspicuous conical peak. Boats awaiting the tide often are off the NW point of this part of the island. Just S of the point are several clusters of mooring piles close-in along the shore, and anchorage in 12 to 18 feet can be secured just NW of the point.

(173) **Beacon Island** marks the turn in the general direction of the pass from N to W. A low-water rocky ledge extends all around the island to the extent of 125 yards E of the island and 200 yards SW of the island. (174) Passage E of Beacon Island leads into **Big John Bay**, a large bay that extends N and E of Horseshoe Island. Fishing vessels often anchor in the SE arm of Big John Bay in 18 to 24 feet, soft bottom. This anchorage is protected from all directions except NW. The N part of Big John Bay is considered good game country. Entering from the W the channel leads N of Horseshoe Island and between the larger two of the islands W of Horseshoe Island.

(175) **Berry Island**, SW of Horseshoe Island and about 1.2 miles WNW of Beacon Island, is small but quite prominent in the vicinity; the vegetation has a rather distinct shade. The island is on the SW part of a reef that extends about 0.3 mile NE. This reef, which covers at half tide, should be given a wide berth.

(176) **Stedman Cove**, the deep bight in the SW shore of **Horseshoe Island**, affords the best anchorage in the vicinity for small craft; it is well protected from almost every direction, particularly from SE and from N to NW. It is a convenient place to await favorable tidal conditions before proceeding S through the pass.

(177) When entering the cove, care should be taken to avoid the long sandspit that extends about two-thirds the distance across the entrance from the E shore. The point of this spit is usually marked by a pole. Continue beyond the second point along the E shore and anchor in 12 to 18 feet in the inner cove.

(178) **Entrance Island**, a long narrow island marking the N entrance to Rocky Pass, is low and wooded to the high-water line. A low-water ledge extends 225 yards off the S shore of the island. Strong tidal currents run around the N end of Entrance Island, and this area is not very favorable for use as an anchorage. Even the head of the bight NE of Entrance Island is a poor anchorage area, being too exposed.

(179) The range of tide at The Summit is about the same as at Ketchikan, but the time of tide occurs about  $\frac{1}{2}$  hour later than at Ketchikan. In the S and N bays of Keku Strait, the range of tide is about 0.8 of that at Ketchikan, and the time of tide is about the same as at Ketchikan. When proceeding in either direction, it is best to enter Rocky Pass about  $1\frac{1}{2}$  to 2 hours before high water. There are many places at each end of Rocky Pass where vessels waiting for the tide can anchor. Strangers should make passage on a rising tide and be careful to remain in the channel because of the many unmarked dangers close to the channel edge. (See the Tide Tables for daily predictions.)

(180) The flood current enters Keku Strait at both ends and meets in varying places between High Island and The Summit. At the entrance to Rocky Pass the tidal current has a velocity at strength of 0.9 to 1.2 knots.

### Corrected through NM Aug. 30/03 Corrected through LNM Aug. 12/03

#### HEIGHTS

Heights in feet above Mean High Water.

#### LOCAL MAGNETIC DISTURBANCE

Differences from the normal variation have been observed in Keku Strait at the following locations:

Lat. 56°38'N, Long. 133°41'W, 3°

Lat. 56°42'N, Long. 133°44'W, 4°

#### SUPPLEMENTAL INFORMATION

Consult U.S. Coast Pilot 8 for important supplemental information.

#### CAUTION

Improved channels shown by broken lines are subject to shoaling, particularly at the edges.

#### POLLUTION REPORTS

REPORTS
Report all spills of oil and hazardous substances to the National Response Center via 1-800-424-8802 (toll free), or to the nearest U.S. Coast Guard facility if telephone communication is impossible (33 CFR 153).

#### WARNING

The prudent mariner will not rely solely on any single aid to navigation, particularly on floating aids. See U.S. Coast Guard Light List and U.S. Coast Pilot for details.

#### RADAR REFLECTORS

Radar reflectors have been placed on many floating aids to navigation. Individual radar reflector identification on these aids has been omitted from this chart.

#### AIDS TO NAVIGATION

Consult U.S. Coast Guard Light List for supplemental information concerning aids to navigation.

#### CAUTION

Temporary changes or defects in aids to navigation are not indicated on this chart. See Local Notice to Mariners.

#### NOTE A

NOTE A
Navigation regulations are published in
Chapter 2, U.S. Coast Pilot 8. Additions or
revisions to Chapter 2 are published in the
Notice to Mariners. Information concerning
the regulations may be obtained at the Office
of the Commander, 17th Coast Guard District
in Juneau, Alaska, or at the Office of the District
Engineer, Corps fo Engineers in Anchorage,
Alaska

Refer to charted regulation section numbers.

#### NOAA WEATHER RADIO BROADCASTS

The National Weather Service stations listed below provide continuous weather broadcasts. The reception range is typically 20 to 40 miles from the antenna site, but can be as much as 100 nautical miles for stations at high elevations.

Sukkwan I. AK	KZZ-89	162,425 MHz
	KZZ-91	162.450 MHz
Zarembo I, AK		
Cape Fanshaw, AK		162.425 MHz
Mount McArthur, AK	KZZ-95	162.525 MHz
Wrangell, AK	WXJ-83	162.40 MHz

#### PLANE COORDINATE GRID (based on NAD 1927)

Alaska State Grid, zone 1, is indicated by dashed ticks at 2,000 foot intervals

The last three digits have been omitted.

#### HORIZONTAL DATUM

The horizontal reference datum of this chart is North American Datum of 1983 (NAD 83), which is North American Dattum or 1983; (NAU 8.9), Wind for charting purposes is considered equivalent to the World Geodetic System 1984 (WGS 84). Geographic positions referred to the North American Datum of 1927 must be corrected an average of 1.258\* southward and 6.306\* westward, to agree with this chart.

PLANE COORDINATE GRID (based on NAD 1927)
Alaska State Grid, zone 1, is indicated by dashed ticks at 2,000 foot intervals
The last three digits have been omitted.

Mercator Projection Scale 1:20,000 at Lat. 56°40' North American Datum of 1983 (World Geodetic System 1984)

> SOUNDINGS IN FEET AT MEAN LOWER LOW WATER

#### **Table of Selected Chart Notes**

This chart has been corrected from the Notice to Mariners (NM) published weekly by the National Imagery and Mapping Agency and the Local Notice to Mariners (LNM) issued periodically by each U.S. Coast Guard district to the dates shown in the lower left hand corner.

#### COLREGS, 80.1705 (see note A)

International Regulations for Preventing Collisions at Sea, 1972. The entire area of this chart falls seaward of the COLREGS Demarcation Line.

This nautical chart has been designed to promote safe navigation. The National Ocean Service encourages users to submit corrections, additions, or comments for improving this chart to the Chief, Marine Chart Division (N/CS2), National Ocean Service, NOAA, Silver Spring, Maryland 20910-3282.

#### TIDAL INFORMATION


Place		Height referred to datum of soundings (MLLW)					
l	Name	(LAT/LONG)	Mean High High Wate		Mean High Water	Mean Low Water	Extreme Low Water
	Monte Carlo I. Beck Island The Summit Entrance Island	(56°32′N/133°46′W) (56°39′N/133°43′W) (56°41′N/133°44′W) (56°49′N/133°47′W)	13.8 15.7		feet 11.7 12.9 14.8 13.8	feet   . 4   . 4   . 6   . 5	feet -4.0 -4.0 -4.0 -4.0

ABBREVIATIONS (For complete list of Symbols and Abbreviations, see Chart No. 1.)
Aids to Navigation (lights are white unless otherwise indicated):

AERO aeronautical	G green IQ interrupted quick Iso isophase		Mo morse code	R TR radio tower Rot rotating	
Al alternating			N nun		
B black			OBSC obscured	s seconds	
Bn beacon	LT HO lighthouse		Oc occulting	SEC sector	
C can	M nautical mile		Or orange	St M statute mile:	
DIA diaphone	m minutes		Q quick	VQ very quick	
F fixed	MICRO TR microwave tower		R red	W white	
FI flashing	Mkr marker		Ra Ref radar reflector	WHIS whistle	
			R Bn radiobeacon	Y yellow	
ottom characteristics:					
Blds boulders	Co coral	gy gray	Ovs oysters	so soft	
bk broken	G gravel	h hard	Rk rock	Sh shells	
Cy clay	Grs grass	M mud	S sand	sy sticky	
fiscellaneous:					
AUTH authorized	Obstn obstruction		PD position doubtful	Subm submerged	


ED existence doubtful PA position approximate Rep reported 21, Wreck, rock, obstruction, or shoal swept clear to the depth indicated.(2) Rocks that cover and uncover, with heights in feet above datum of soundings.

This nautical char; has been designed to promote safe navigation. The National Ocean Service encourages users to submit corrections, additions, or comments for improving this chart to the Chief, Marine Chart Division (N/CS2), National Ocean Service, NOAA, Silver Spring, Maryland 20910-3282. NOAA and its partner, OceanGraftx, offer this is chart updated weekly by NOAA for Notices to Mariners and critical corrections. Charts are printed when ordered using Print-on-Demand technology. New Editions are available 5-8 weeks before their release as traditional NOAA charts. Ask your chart agent about Print-on-Demand charts or contact NOAA at 1-800-584-4683, http://NauticalCharts.gov, help@NauticalCharts.gov, or OceanGrafix at 1-877-56CHART, http://OceanGrafix.com, or help@OceanGrafix.com.











This BookletChart was reduced to 75% of the original chart scale. The new scale is 1:26667. Barscales have also been reduced and are accurate when used to measure distances in this BookletChart.







This BookletChart has been updated with: Coast Guard Local Notice To Mariners: 0710 2/16/2010,


NGA Weekly Notice to Mariners: 0910 2/27/2010,

Canadian Coast Guard Notice to Mariners: 0909 9/25/2009.







































11th Ed., Sep / 03 
Corrected through NM Aug. 30/03 
Corrected through LNM Aug. 12/03 
17372

CAUTION

This chart has been corrected from the Notice to Mariners (NM) published weekly by the National Imagery and Mapping Agency and the Local Notice to Mariners (LNM) issued periodically by each U.S. Coast Guard district to the dates shown in the lower left hand correr.


16






Published at Washington, D.C. U.S. DEPARTMENT OF COMMERCE NATIONAL OCEANIC AND ATMOSPHERIC ADMINISTRATION NATIONAL OCEAN SERVICE COAST SURVEY

## SOUNDINGS IN F









### **EMERGENCY INFORMATION**

#### VHF Marine Radio channels for use on the waterways:

Channel 6 – Inter-ship safety communications.

**Channel 9** – Communications between boats and ship-to-coast.

**Channel 13** – Navigation purposes at bridges, locks, and harbors.

#### Channel 16 – Emergency, distress and safety calls

to Coast Guard and others, and to initiate calls to other vessels. Contact the other vessel, agree to another channel, and then switch.

**Channel 22A** – Calls between the Coast Guard and the public. Severe weather warnings, hazards to navigation and safety warnings are broadcast here.

Channels 68, 69, 71, 72 & 78A – Recreational boat channels.

#### **Distress Call Procedures**

- 1. Make sure radio is on.
- 2. Select Channel 16.
- 3. Press/Hold the transmit button.
- 4. Clearly say: "MAYDAY, MAYDAY, MAYDAY."
- Also give: Vessel Name and/or Description; Position and/or Location; Nature of Emergency; Number of People on Board.
- 6. Release transmit button.
- Wait for 10 seconds If no response Repeat MAYDAY Call.

#### HAVE ALL PERSONS PUT ON LIFE JACKETS!!

#### **Mobile Phones** – Call 911 for water rescue.

Coast Guard Search & Rescue (Pacific Coord) – 510-437-3700

Coast Guard Search & Rescue (RCC Juneau) – 907-463-2000

<u>NOAA Weather Radio</u> – 162.400 MHz, 162.425 MHz, 162.450 MHz, 162.475 MHz, 162.500 MHz, 162.525 MHz, 162.550 MHz.

Getting and Giving Help – Signal other boaters using visual distress signals (flares, orange flag, lights, arm signals); whistles; horns; and on your VHF radio. You are required by law to help boaters in trouble. Respond to distress signals, but do not endanger yourself.



## NOAA CHARTING PUBLICATIONS

Official NOAA Nautical Charts – NOAA surveys and charts the national and territorial waters of the U.S, including the Great Lakes. We produce over 1,000 traditional nautical charts covering 3.4 million square nautical miles. Carriage of official NOAA charts is mandatory on the commercial ships that carry our commerce. They are used on every Navy and Coast Guard ship, fishing and passenger vessels, and are widely carried by recreational boaters. NOAA charts are available from official chart agents listed at: <a href="https://www.NauticalCharts.NOAA.gov">www.NauticalCharts.NOAA.gov</a>.

Official Print-on-Demand Nautical Charts — These full-scale NOAA charts are updated weekly by NOAA for all Notice to Mariner corrections. They have additional information added in the margin to supplement the chart. Print-on-Demand charts meet all federal chart carriage regulations for charts and updating. Produced under a public/private partnership between NOAA and OceanGrafix, LLC, suppliers of these premium charts are listed at www.OceanGrafix.com.

#### Official Electronic Navigational Charts (NOAA ENCs®) -

ENCs are digital files of each chart's features and their attributes for use in computer-based navigation systems. ENCs comply with standards of the International Hydrographic Organization. ENCs and their updates are available for free from NOAA at www.NauticalCharts.NOAA.gov.

#### Official Raster Navigational Charts (NOAA RNCs<sup>™</sup>) –

RNCs are geo-referenced digital pictures of NOAA's charts that are suitable for use in computer-based navigation systems. RNCs comply with standards of the International Hydrographic Organization. RNCs and their updates are available for free from NOAA at <a href="https://www.NauticalCharts.NOAA.gov">www.NauticalCharts.NOAA.gov</a>.

Official BookletCharts<sup>™</sup> – BookletCharts<sup>™</sup> are reduced scale NOAA charts organized in page-sized pieces. The "Home Edition" can be downloaded from NOAA for free and printed. The Internet address is www.NauticalCharts.gov/bookletcharts.

Official PocketCharts<sup>TM</sup> – PocketCharts<sup>TM</sup> are for beginning recreational boaters to use for planning and locating, but not for real navigation. Measuring a convenient 13" by 19", they have a 1/3 scale chart on one side, and safety, boating, and educational information on the reverse. They can be purchased at retail outlets and on the Internet.

Official U.S. Coast Pilot® – The Coast Pilots are 9 text volumes containing information important to navigators such as channel descriptions, port facilities, anchorages, bridge and cable clearances, currents, prominent features, weather, dangers, and Federal Regulations. They supplement the charts and are available from NOAA chart agents or may be downloaded for free at <a href="https://www.NauticalCharts.NOAA.gov">www.NauticalCharts.NOAA.gov</a>.

Official On-Line Chart Viewer – All NOAA nautical charts are viewable here on-line using any Internet browser. Each chart is up-to-date with the most recent Notices to Mariners. Use these on-line charts as a ready reference or planning tool. The Internet address is www.NauticalCharts.gov/viewer.

Official Nautical Chart Catalogs – Large format, regional catalogs are available for free from official chart agents. Page size, state catalogs are posted on the Internet and can be printed at home for free. Go to <a href="http://NauticalCharts.NOAA.gov/mcd/ccatalogs.htm">http://NauticalCharts.NOAA.gov/mcd/ccatalogs.htm</a>.

Internet Sites: <a href="https://www.Noa.gov">www.Noa.gov</a>, <a href="